


2009 SEA-DOO  
4-TEC-iTC SERIES

COLOR TABLE

WH = WHITE	BK = BLACK
RD = RED	YL = YELLOW
VI = VIOLET	BE = TAN
GN = GREEN	BR = BROWN
GY = GREY	BU = BLUE
PK = PINK	OR = ORANGE



FUSE BOX -1-

1. 3A GAUGE CADRAN	2. 3A CAPS CRAC	3. 3A DEPTH SOUNDER SOL. DENH	4. 5A STARTER SOL. SW. / INTERR.	5A iBR CTRL	6. 10A FUEL PUMP POMPE ESSENCE
7. 10A CYL.1	8. 10A CYL.2	9. 10A CYL.3	10. 3A OTAS SW. / INTERR.	11. 5A IS CTRL	

+12 VOLTS ACCESSORY

+12 VOLTS ACCESSORY

FUSE BOX -2-

RELAY 30A	15. 30A CHARGE	+12 VOLTS	16. 30A IS	17. 30A BATT.
-----------	----------------	-----------	------------	---------------

+12 VOLTS

COMMUNICATION (CAN HI)		COMMUNICATION (CAN LOW)	
18. 30A iBR		20. 15A ECM	21. 3A START / STOP SW. / INTERR.
GROUND / MASSE		22. 15A DIAG TOOL OUTIL DIAG.	23. 3A GPS