


2009 SEA-DOO
4-TEC-iTC IS SERIES

COLOR TABLE	
WH = WHITE	BK = BLACK
RD = RED	YL = YELLOW
VI = VIOLET	BE = TAN
GN = GREEN	BR = BROWN
GY = GREY	BU = BLUE
PK = PINK	OR = ORANGE



FUSE BOX -2-

RELAY 30A	15. 30A CHARGE	+12 VOLTS	16. 30A iS	17. 30A BATT.
+12 VOLTS				
COMMUNICATION (CAN HI)		COMMUNICATION (CAN LOW)		
18. 30A IBR		20. 15A ECM	21. 3A START / STOP SW. / INTERR.	
GROUND / MASSE		22. 15A DIAG TOOL OUTIL DIAG.	23. 3A GPS	

CHARGING SYSTEM

OPERATION:

- 1- FUSE 15 IS GOOD.
- 2- ACG SENDS CURRENT TO VOLTAGE REGULATOR / RECTIFIER
- 3- VOLTAGE REGULATION AND CURRENT RECTIFICATION FROM ALTERNATIVE CURRENT (AC) TO DIRECT CURRENT (DC).
- 4- DIRECT CURRENT CHARGES BATTERY.