


2010 SEA-DOO
4-TEC-iTC-IS SERIES

COLOR TABLE

WH = WHITE	BK = BLACK
RD = RED	YL = YELLOW
VI = VIOLET	BE = TAN
GN = GREEN	BR = BROWN
GY = GREY	BU = BLUE
PK = PINK	OR = ORANGE



FUSE BOX -1-

1. GAUGE CADRAN	3A	2. CAPS CRAC	3A	3. DEPTH SOUNDER SOL. DEPT	3A	4. STARTER SOL. SW. / INTERR	5A	5. iBR CTRL	5A	6. FUEL PUMP POMPE ESSENCE	10A
7. CYL.1	10A	8. CYL.2	10A	9. CYL.3	10A	10. OTAS SW. / INTERR	3A	11. IS CTRL	5A		

+12 VOLTS ACCESSORY

+12 VOLTS ACCESSORY

FUSE BOX -2-

RELAY	30A	15. CHARGE	30A	+12 VOLTS	16. IS	30A	17. BATT.	30A
-------	-----	------------	-----	-----------	--------	-----	-----------	-----

+12 VOLTS

COMMUNICATION (CAN HI)		COMMUNICATION (CAN LOW)	
18. iBR	30A	20. ECM	15A
GROUND / MASSE		21. START / STOP SW. / INTERR	3A
		22. DIAG TOOL OUTIL DIAG	15A
		23. GPS	3A