2011 SEA-DOO
4-TEC-iTC SERIES

COLOR TABLE	
WH = WHITE	BK = BLACK
RD = RED	YL = YELLOW
VI = VIOLET	BE = TAN
GN = GREEN	BR = BROWN
GY = GREY	BU = BLUE
PK = PINK	OR = ORANGE

DIAG TOOL
120 OHMS
GY-RD
RD-VI
BK — FB1-H3
WH-BK — FB1-G6
WH-RD — FB1-G12

START / STOP SW (NORMALY OPEN)
VTS AND iS SW.
MODE / SET SW. UP / DOWN SW.
CRUISE (NORMALY OPEN)
STEERING
GAUGE
TAS
ENGINE CUT-OFF SWITCH (DESS)
FB1-H7
FB1-G5
FB1-G11

FUSE BOX (FB1)
BUS CAN HI
BUS CAN LOW
BUS 12 V
BUS 12 V
BUS 12 V
BUS GROUND
BUS 12V ACCESSORY
BUS 12V ACC
RELAY
FUEL PUMP
FUEL LEVEL SENSOR
OTAS
CAPS
CAM SENSOR EQUIPPED ONLY

ECM
MAPS
THROTTLE BODY WITH INTEGRATED MOTOR ACTUATOR
CPS
MATS
CTS
T.O.P.S.
OPS (NORMALLY CLOSED)
KNOCK SENSOR
EGTS

VOLTAGE REGULATOR / RECTIFIER
CONTROL CIRCUIT
AC GENERATOR
ENGINE GROUND
iBR
iBR MOTOR
SUSPENSION POSITION SENSOR
iS
iS MOTOR
iS SERIE ONLY
BRLS
ENGINE CO4-4POS.
FUEL INJECTOR # 1
IGNITION COIL # 1
FUEL INJECTOR # 2
IGNITION COIL # 2
FUEL INJECTOR # 3
IGNITION COIL # 3
BATTERY
STARTER MOTOR
STARTER SOLENOID
DEPTH SOUNDER
GTX iS LTD ONLY

30A RELAY	1. 5A IS CTRL	2. 15A DIAG TOOL	3. 3A START/STOP	4. 3A GPS	5. 30A IBR	6. 30A CHARGE	7. 30A IS	8. 30A BATT.
+12 VOLTS ACCESSORY	+12 VOLTS						+12 VOLTS	
+12 VOLTS ACCESSORY								
9.	10.	11. 3A DEPTH SOUNDER	12. 3A HANDLE CTRS + CSPS	13. 10A CYL.1	14. 10A CYL.2	15. 10A CYL.3	16. 5A STARTER SOL.	17. 5A IBR CTRL	18. 10A FUEL PUMP	19. 15A ECM
COMMUNICATION (CAN HI)		COMMUNICATION (CAN LOW)								
+12 VOLTS ACCESSORY		GROUND								

FUSE BOX DECAL (FB1)